

## The Bedding in procedure

Bedding in is vital after fitting new pads, discs or shoes. Here are some instructions on bedding in the EPB shoes.

- With the Engine running, press the brake pedal fully on and off 3 times. On the third press, hold the brake pedal down.
- With the brake pedal still in the down position, pull the EPB switch upwards 4 times and then downwards 3 times. This must be completed within 10 seconds.
- Your dash display will then show 'Park Brake Bedding Cycle Active' or something similar. If it hasn't, then release the brake pedal and try again.
- You need to ensure that you are on a clear piece of road or land as this procedure needs to be completed 10 times.
- Drive at least 19mph and maximum of 29mph and then apply the EPB switch until you stop. You then need to wait for 60 seconds or drive for 1 mile (to allow the brakes to cool down before repeating the process. If you stop the engine or you drive over 30 MPH, the bedding in process will be cancelled. At the end of the 10th time, the bedding in mode will automatically finish.

To prevent the same failure happening to the new parts, we recommend that the parking brake shoes are adjusted at every service. We also recommend stripping down and cleaning the rear brakes thoroughly every two years.

For further reference, a Landrover technical bulletin can be found upon searching the internet for 'LTB00079v6' or by using [www.landrovertchinfo.com](http://www.landrovertchinfo.com)

**CAUTION! Failure to follow these steps may cause damage to the park brake system.**